

Door Numbering

The door numbering scheme used in all UAF Construction Documents shall be based on the room numbering scheme. Generally, the number of the door shall be the same as the number of the room being entered (example: For room “266”, the door numbers are “266.1” and “266.2”). In rooms with more than one door, the doors shall be numbered starting at the North-West corner of the room and moving counter-clockwise around the room (see figure 1 – for example, in room “269”, the numbering of the doors starts at the North-West corner moving counter-clockwise with door one “269.1” being located on the West wall).

When doors occur between adjacent rooms that both have their main entry door off of corridors, these doors will be identified with the lower room number (example: the door between room “260” and room “262” will be “260.1”). When a room can only be entered through another room, the door will be identified with the room being entered. If a door has a locking cylinder on each side, the door will have a different door number on each side (example: Door “210.1A” on one side and “210.1B” on the other side). Stairwell doors to corridors are always numbered to the stairwell side.

In cases of renovations to rooms where doors are added, the new doors will be identified with the next available door number for that room.

Example of acceptable door numbering:

Figure 1:

